




# Samsung Galaxy S5 Mini SIM & SD card reader Replacement

Written By: Sophia





## TOOLS:

- [Heat Gun](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [Spudger](#) (1)



## PARTS:

- [Samsung Galaxy S5 Mini SIM & SD card reader](#) (1)

## Step 1 — SIM & SD card reader



- Remove back cover.

## Step 2



- Remove battery. If you have SIM card and SD card in, remove them by the way.

## Step 3



- Open this cover and release the home button flex connector.

## Step 4



- Heat the screen, cut the sticker under it and release the screen connector. Please be careful with the screen flex when sliding to cut the sticker.

## Step 5



- Remove the LCD screen from rear case.


## Step 6



- Remove all the screws.



## Step 7






- Get loosen the touch keys from adhesive, and then push the mid-plate out from the middle housing.

## Step 8



- Twist off these two screws and remove the whole motherboard assembly.

## Step 9



- Release the connector, loose the assembly from adhesive and remove it finally.

---

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 06:56:05 AM.